

RHC Tubeless Rim tape

- Lightweight Tubeless Rim Tape
- High strength
- Tear Resistance

22mm width will fits 700c Road rims; Mountain Bike rims.
This roll is enough for two 700c or 29er wheels.

Step-by-step Direction.

Step 1 - Clean the rim preferably with spirit to remove any sticker or glue stain on the inside of the rim.

Step 2 - Line up the end of the tape about 3 inches beyond the valve stem hole. From that point, begin taping the rim with firm stretch all the way around.

Step 3 - Overlap the tape about 5 inches over the valve stem hole.

Step 4 - Using a sharp pointed tool such as a pencil or pen, punch holes through the tape at the valve stem of each rim, toward the hub.

The next step, follow the instruction on how to install the *RHC Tubeless Valve*.

The Complete Tubeless conversion instruction can be found at *RHC Tubeless Conversion system*.